

Incini-Cone v1.1 Spares List

Contact Eclipse for Ordering Information

Model IC0136

00.4360003.01	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

Model IC0224

00.4360003.02	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

Model IC0360

00.4360003.03	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

Model IC0500


00.4360003.04	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

Model IC0680

00.4360003.05	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

Model IC0900

00.4360003.06	Firing Cone
00.4360004.17	Igniter Assembly
120051	Peepsight
00.4360004.07	Pilot



Model IC1480

00.4360003.07	Firing Cone
00.4360004.17	Igniter Assembly
120051	Peepsight
00.4360004.07	Pilot

Model IC1780

00.4360003.08	Firing Cone
00.4360004.18	Igniter Assembly
120051	Peepsight
00.4360004.08	Pilot

Model IC2690

00.4360003.09	Firing Cone
00.4360004.19	Igniter Assembly
120051	Peepsight
00.4360004.09	Pilot